

**W300 Features<sup>1)</sup>**

Walkman® player	Face warp
Stereo headphones	Wallpaper
Disc2Phone PC software	Themes
Music mode (transmitter off)	
PlayNow™	Push e-mail
Audio file formats:	SMS & MMS (Multimedia Messaging)
MP3 and AAC	Predictive text input
Audio file extensions:	WAP 2.0 XHTML/HTML
.mp3, .mp4, .m4a and .wav	Access NetFront™ web browser
Polyphonic ringtones, 40 voices	Java MIDP 2.0
FM radio with RDS	
MusicDJ™	
Speakerphone	Alarm clock
Sound recorder	Calendar
	Contacts
	File manager
2D and 3D gaming	
VGA camera	Infrared
Video play and record	Bluetooth™
Video file formats:	USB 2.0 mass storage
3GPP and MPEG-4	USB cable
Video file extensions:	Memory Stick Micro™ (M2™)
.3gp and .mp4	support (up to 1GB)
Picture caller ID	Modem
PhotoDJ™	PC synchronization
VideoDJ™	

**W300 Facts<sup>1) 2)</sup>**

Size: 90 x 47 x 24.5 mm	Main screen
Weight: 94 grams	Type: 1.8" 262,144 color TFT
	Resolution: 128 x 160 pixels
Networks:	External display
Quad band	Type: 1" Monochrome
GSM/GPRS/EDGE	Resolution: 101 x 80 pixels
850/900/1800/1900	
Colors:	Memory size, internal: 20 MB
Shadow Black	Memory Stick Micro™ (M2™): 256 MB
Shimmering White	Talk time: Up to 9.5 hours
	Standby time: Up to 400 hours

**W300 Downloads**

Image Editor	Ringtones
MMS home studio	Games
Automatic messaging configurator	Themes
Sync software	Applications
Wallpapers	

At [www.sonyericsson.com](http://www.sonyericsson.com), you have great W300 content waiting for you.

<sup>1)</sup>Facts and features may vary depending on local variant. Increased capacity Memory Stick Micro™ (M2™) memory cards will be supported as they become available.

<sup>2)</sup>Talk and standby times are affected by network preferences, type of SIM card, connected accessories and various activities e.g. games.

The full range of accessories may not be available in every market. Kit contents and color options may differ from market to market. Subject to change without prior notice.

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Sony Ericsson is under license.

Memory Stick Micro™ and M2™ are registered trademarks of Sony corporation. Other trademarks and trade names are those of their respective owners.



# W300

## Walkman® phone

W300c • W300i



# Sony Ericsson

# Let it entertain you



Surf the sound waves with the W300 Walkman® phone. Everything you need is in the kit. Just add music and let it entertain you.



Walkman® is a registered trademark of Sony Corporation

## It's all in the mix



Listen to your best music between calls and texting. You can store up to 60\* tracks on the included 256 MB Memory Stick Micro™ (M2™) memory card.



You also get a USB cable for connecting the phone to a PC, stereo headphones and music management PC software for converting songs and transfer them to the W300 Walkman® phone.

\*Assumes MP3 encoding at CD quality, 4 min/track

## Tune in and chill out



Start the Walkman® player by pressing the orange music key on the left-hand side of the phone to listen to songs or watch video clips. You set up your own playlists and adjust the bass and treble sound with the graphical equalizer. Choose Shuffle when you want to hear songs in random order and Loop when you want to listen to your favorite playlist all over again.



The W300 can be used in music mode only, with the radio transmitter turned off – a useful feature when for instance travelling by airplane. You can listen to music for up to 30 hours with the W300. Incoming calls stop the music, which starts again as soon as you hang up.

## Fully-featured FM radio



The stereo FM radio provides you with entertainment day and night. The FM radio of the W300 features RDS (Radio Data System). RDS enables radio stations to send traffic reports, special offers and other types of information to the radio to be shown on the screen.



Listen to the radio or music with the included headphones or your own standard headphones with a 3.5 mm plug.

## Show someone



The pictures you take with the built-in camera are perfect for MMS messages and e-mail. Take a snap and share it immediately. Or use an infrared or a Bluetooth™ connection to send it to a phone close by.

## Browse to music



The W300 lets you do other things while the music or radio is playing. Hide the Walkman® player or minimize the radio to write a text message, play games or browse the web. The Access NetFront™ browser handles full HTML pages making it possible for you to visit your favorite web pages also when you are away from your computer.

## Accessories for the W300

### Portable Speakers MPS-60



These small yet powerful neodymium magnet speakers fit easily in your pocket. Share phone-based music with your friends or enjoy your favorite radio show through the integrated FM antenna. A truly portable music accessory, the MPS-60 is powered by the phone. Enjoy phone-based music for up to 5 hours.

### Music Power Pack MPP-60



This is an easy way to connect mobile phone to hi-fi system. Put your phone in the cradle of the desk stand. Connected to your hi-fi system, the attached music cable allows you to listen to phone-based music in stereo loudspeakers. The included charger ensures that you do not run out of power.

### FM Music Transmitter MMR-60



Unleash your music – tune in to your own radio playlist. Branded with the Walkman® logotype, the MMR-60 transmits your favorite phone-based songs over the FM radio frequency band. The last used frequency appears when you reconnect your phone, making it easy to enjoy music wherever there is a radio.

LIMITED MARKET AVAILABILITY

For complete list of W300 compatible accessories, go to [www.sonyericsson.com](http://www.sonyericsson.com)